


## FXCG Downloads

Steps to download programs and eActivities to your Casio fx-CG calculator.

**Key idea - your calculator can act as a USB drive!**

1. Download items from website such as [charliewatson.com/fxcg/](http://charliewatson.com/fxcg/) by clicking on link - item will automatically be saved in your downloads folder.
2. Use a USB cable to plug your calculator into your computer (Mac or PC). Tap F1 on the calculator when prompted for Connection Mode.
3. Open a folder window on your computer and find and open the drive that is your calculator.



4. Transfer items as follows:  
  
eActivities (\*.g3e) - drag and drop into top level folder.  
  
Programs (\*.g3m) - click into the @MainMem folder and then into PROGRAM folder. Drag and drop programs into this folder.
5. Eject the drive that is your calculator and disconnect USB cable.

*Most of the fx-CG range of calculators have a measly 4 or 5 MB of memory, so you won't be using it to replace your regular USB drive, but that's enough room for hundreds of programs (typically 1 to 2 KB each) and eActivities (typically 3 to 8 KB each).*